

Microwave Oven (No handle) - User Manual

General Notes

To turn on - Press the right dial

To turn off - Press and Hold the right dial

To display cooking functions - Press the right dial while oven is on

To open door - Press the left dial

Please do not use metal products in the Microwave-Oven. With the exception of the Fan Oven & Grill settings only

Please only insert microwave suitable glass/plates

Microwave-Grill Functions (from left to right as appears on screen) - Microwave, Microwave & Grill, Grill only, Defrost by time, Defrost by weight, Pizza.

Instructions

Microwave

- 1) Select the microwave setting by turning the right dial to the right 1 time
- 2) Use the left dial to adjust the amount of time
- 3) Press the right dial to start cooking
- 4) To Pause, press the right dial.
- 5) To turn off, press and hold the right dial

Microwave & Grill

1. Select the Microwave & Grill setting by turning the right dial to the right 2 times
2. Use the left dial to adjust the amount of time
3. Press and Hold the left dial to adjust the Power Level
4. Press the right dial to start cooking

Grill

- 1) Select the Grill setting by turning the right dial to the right 3 times
- 2) Use the left dial to adjust the amount of time
- 3) Press the right dial to start cooking

Defrost (by time)

- 1) Select the defrost by time function by turning the right dial to the right 4 times
- 2) Use the left dial to adjust the amount of time
- 3) Press the right dial to start defrosting

Defrost (by weight)

- 1) Select the defrost by Grams (g) function by turning the right dial to the right 5 times
- 2) Use the left dial to adjust the defrost setting between Pr 1 -5
 - PR 1 = Meat
 - PR 2 = Poultry
 - PR 3 = Fish
 - PR 4 = Fruit
 - PR 5 = Bread
- 3) Use the left dial to adjust time
- 4) Press and hold the left dial to move to the weight section (measured in grams)
- 5) Using the left dial to adjust the weight
- 6) Press the right dial to start

Pizza

- 1) Select the Pizza function by turning the right dial right 5 times
 - The timer is pre-set to 7 minutes and is suitable for pizza of 200g
- 2) Press the right dial to start
 - If more time is needed you may restart pizza function or use grill function

Please contact the front desk if you are having any issues.